

Dealer Price List for Pixel Product Line April 2017

Qty	Order Code	UPC CODE	PRODUCT #	Model	Product Description	Pixel MSRP
				KING Wireless TTL Flash Trigger		
	APXK01C	489 51523 05310	King For Canon	King Kit For Canon	Wireless TTL Flash Trigger (Full Set)	\$249.95
	APXK01N	489 51523 05358	King For Nikon	King Kit For Nikon	Wireless TTL Flash Trigger (Full Set)	\$249.95
	APXK01RC	489 51523 05334	King RX For Canon	King RX RECEIVER For Canon	Wireless TTL Flash Trigger (Receiver Only)	\$149.95
	APXK01RN	489 51523 05372	King RX For Nikon	King RX RECEIVER For Nikon	Wireless TTL Flash Trigger (Receiver Only)	\$149.95

SOLDIER Wireless Flash Grouping/Shutter Remote Control

	APXS01N	489 51523 03071	TF-372	Soldier Kit For Nikon	Wireless Flash Grouping/Shutter Remote Control (Full Set)	\$99.95
	APXS01S	489 51523 03156	TF-373	Soldier Kit For Sony	Wireless Flash Grouping/Shutter Remote Control (Full Set)	\$99.95
	APXS01PO	489 51523 03194	TF-374	Soldier Kit For Pan/Oly	Wireless Flash Grouping/Shutter Remote Control (Full Set)	\$99.95
	APXS01RC	489 51523 03057	TF-371 RX	Soldier RX RECEIVER For Canon	Wireless Flash Grouping/Shutter Remote Control (Receiver Only)	\$69.95
	APXS01RN	489 51523 03132	TF-372 RX	Soldier RX RECEIVER For Nikon	Wireless Flash Grouping/Shutter Remote Control (Receiver Only)	\$69.95
	APXS01RS	489 51523 03170	TF-373 RX	Soldier RX RECEIVER For Sony	Wireless Flash Grouping/Shutter Remote Control (Receiver Only)	\$69.95
	APXS01RPO	489 51523 03231	TF-374 RX	Soldier RX RECEIVER For Pan/Oly	Wireless Flash Grouping/Shutter Remote Control (Receiver Only)	\$69.95

Connecting Cables

	APXCLDC0	489 51523 03316	CL-DC0	CL-DC0 for Nikon D800/700/300/D2/D1/200/D4/N90s/F5/F6/F100/F90/F90 X/Fuji S5 PRO/S3 PRO/Kodak DCS-14N	Camera Connecting Cable (2.5MM)	\$9.95
	APXCLDC1	489 51523 03330	CL-DC1	CL-DC1 for Nikon D80/70s	Camera Connecting Cable (2.5MM)	\$9.95
	APXCLDC2	489 51523 03354	CL-DC2	CL-DC2 for Nikon D7000/5100/5000/3200/3100/90	Camera Connecting Cable (2.5MM)	\$9.95
	APXCLN3	489 51523 03378	CL-N3	CL-N3 for Canon EOS 7D/5D/1D/50D/40D/30D/20D/10D	Camera Connecting Cable (2.5MM)	\$9.95
	APXCLN3X	489 51523 03392	CL-N3+	CL-N3 for Canon EOS 7D/5D/1D/50D/40D/30D/20D/10D	Camera Connecting Cable (2.5MM)	\$17.95
	APXCLE3	489 51523 03415	CL-E3	CL-E3 for Canon Powershot G10/G11/G12/G1X; EOS 1100D/1000D/T2i/T3i/T4i/650D/600D/550D/500D/450D/400D/350D/300D/60D; Pentax K5/K7/K10/K20/K100/K200; Samsung GX-1L/1S/10/20/NX100/NX11/NX10/NX5; Contax 645/N1/NX/N digital	Camera Connecting Cable (2.5MM)	\$9.95
	APXCLS1	489 51523 03439	CL-S1	CL-S1 for Sony DSLR a900/850/700/560/550/500/450/400/350/300/200/100/77/65/57/55/35/33	Camera Connecting Cable (2.5MM)	\$9.95
	APXCLCB1	489 51523 03453	CL-CB1	CL-CB1 for Olympus E1/3/10/20/5	Camera Connecting Cable (2.5MM)	\$9.95
	APXCLU1	489 51523 03477	CL-UC1	CL-UC1 for Olympus E620/600/550/450/450/420/410/400/100/30/PMI/M5; PEN EPI2/PL3/P3/EP-2/EP-1; SP590UZ/570UZ/565UX/560UZ/550UZ/510UZ/810UZ; SZ-30MR/20/11; XZ-1	Camera Connecting Cable (2.5MM)	\$9.95
	APXCLL1	489 51523 03491	CL-L1	Panasonic: DMC-FZ50, DMC-FZ50K, DMC-FZ50S, DMC-FZ30, DMC-FZ30K, DMC-FZ30S, DMC-FZ20, DMC-FZ20K, DMC-FZ20S, LC-1, L1. Leica: DIGILUX2, DIGILUX3	Camera Connecting Cable (2.5MM)	\$9.95
	APXCLPC	430 4811 988023	CL-PC	2.5mm to PC	Connecting Cable for Studio Lights	\$17.95
	APXCL35	430 4811 988021	CL-3.5	2.5mm to 3.5mm	Connecting Cable for Studio Lights	\$17.95
	APXPCPC	489 51523 03576	PC-PC	PC to PC	Connecting Cable for Studio Lights	\$17.95
	APXPC35	430 4811 988025	PC-3.5	PC to 3.5mm	Connecting Cable for Studio Lights	\$17.95
	APXPC12	430 4811 988026	PC-1/2	PC to 1/4 inch	Connecting Cable for Studio Lights	\$17.95

Cable Shutter Remote

	APXRCS1	489 51523 00117	RC-201/S1	RC-201/S1 for Sony	Cable Shutter Remote	\$11.95
				Wireless Timer Remote Control		
	APX282N	489 51523 00612	TW-282/DC0	TW-282/DC0 for Nikon	Wireless Timer Remote Control	\$99.95
	APX282N2	489 51523 00650	TW-282/DC2	TW-282/DC2 for Nikon	Wireless Timer Remote Control	\$99.95
	APX282C2	489 51523 00674	TW-282/N3	TW-282/N3 for Canon	Wireless Timer Remote Control	\$99.95
	APX282S	489 51523 00711	TW-282/S1	TW-282/S1 for Sony	Wireless Timer Remote Control	\$99.95

TTL Extension Cords

	APXFC311L	489 51523 01619	FC-311/L	FC-311 Cannon/L 10M	TTL Extension Cord (Small)	\$54.95
	APXFC311M	489 51523 01732	FC-311/M	FC-311 Cannon/M 3.6M	TTL Extension Cord (Small)	\$36.95
	APXFC312S	489 51523 01756	FC-311/M	FC-312 Nikon/S 1.8M	TTL Extension Cord (Small)	\$29.95
	APXFC313S	489 51523 01794	FC-313/S	FC-313 Sony/S 1.8M	TTL Extension Cord (Small)	\$29.95
	APXFC312M	489 51523 01770	FC-312/M	FC-312 Nikon/M 3.6M	TTL Extension Cord (Small)	\$36.95

Hotshoe Adapter

	APXTF322	489 51523 01930	TF-322	TF-322 For Nikon	Hotshoe Adapter w/shoe on top	\$15.95
	APXTF323	489 51523 01954	TF-323	TF-323 For Sony	Hotshoe Adapter w/shoe on top	\$15.95
	APXTF324	489 51523 01978	TF-324	TF-324 For	Hotshoe Adapter w/shoe on top	\$15.95
	APXTF325	489 51523 01992	TF-325	TF-325 For	Hotshoe Adapter w/shoe on top	\$15.95
	APXTF326	489 51523 02012	TF-326	TF-326 For Canon	Hotshoe Adapter	\$15.95
	APXTF327	489 51523 02036	TF-327	TF-327 For Nikon	Hotshoe Adapter	\$15.95
	APXTF328	489 51523 02050	TF-328	TF-328 For Sony	Hotshoe Adapter	\$15.95
	APXTF321	489 51523 01916	TF-321 NEW	TF-321 New	Hotshoe Adapter (Canon) with TTL	\$16.95

Battery Grip

	APXVD90		VD90	VD90 for Nikon D90	Battery Grip Nikon D90	\$79.95
	ASA675		JND2005	Jenis Power Grip f/D200/S5	Power Grip	\$149.95